

# Fitting QUARRYCAST™ feet

The fitting of the bath feet and installation of the bath will be seen as acceptance of quality. We strongly recommend that you use a suitably qualified installer. Instructions must be adhered to. We cannot accept responsibility of incorrect installation.

If the bath has been painted ensure the contact area on the bath where the feet will fit has not been painted over as this could result in poor adhesion and possible failure.

**Please note:** The silicon tube contains the correct amount of adhesive for the feet supplied. Be careful not to over apply on the first foot. Silicon should be used before the expiry date printed on the tube.

Additional supplies of general purpose clear medium/high modulus silicon are available from all good DIY stores. Do not use adhesives.

**Important:** Roxburgh and Shropshire slipper baths have unique front and back feet. Prior to fitting, ensure the colour coding is correctly matched.

## Attaching the feet to the bath

### Standard white resin feet



A. With the bath upside down, apply one quarter of the silicon in small thin beads to the contact area of the foot.



B. Align the foot and press firmly into position, forcing it to bed-down.



C. Repeat this process for the three remaining feet.

D. Leave the bath upturned for 12 hours. Trim any excess silicon and turn the bath on its feet.

## Attaching your bath to the floor

For your safety we have included a fixing kit to level and secure the bath to the floor and we recommend it be used in all installations.

The kit consists of four adjustable metal bolts, four ground anchors and four screws.

A. Prior to securing, check the bath is square on all four feet. If necessary the feet can be filed down or discretely packed out to eliminate rock caused by an uneven floor.



B. Thread the screw through the counter sunk hole in the metal plate and screw into the predrilled hole in the bottom of the bath leg.

Repeat this process with all four legs.



C. Secure the bath to the floor using a suitable fixing method for your floor type. The floor fixing plates can be set at an angle so that they are out of view.



**plumbworld**  
**Big brands, small prices.**

Pdf Supplied By <http://www.plumbworld.co.uk/>