

Fitting the Marlborough

The fitting of the bath will be seen as acceptance of quality. We strongly recommend that you use a suitably qualified installer.

Instructions must be adhered to. We cannot accept responsibility of incorrect installation.

We recommend that the first fix of this bath be done prior to laying the final floor.

Installation away from walls

- A. Position base on floor and mark position.



- B. Place bathtub on pedestal to ensure correct position and mark centre of the waste outlet onto the floor.
- C. Lay suitable pipe work. It will be necessary to cut a small hole in the floor to accommodate the p-trap that must be used.



- D. Remove base, lay flooring then fit the plinth to the floor using the screws provided.
- E. Assemble overflow pipe.
- F. Apply silicon provided in a zigzag pattern to the base. Place bath on base and leave overnight for the silicone to cure.



- G. Install overflow kit.



Installation against the wall

If you plan to install the bath in a location with restricted rear access we suggest the following fitting method:

- A. Position base on floor and mark position.
- B. Mark centre of the waste hole on the floor. Remove bath and position waste pipe approximately 300mm from the trap outlet.
- C. Silicone the bath to the base and fit the waste kit. Connect a 500mm length of flexible waste pipe to the p-trap and check the whole assembly for leaks.
- D. Reposition the bath and tilt forwards. Connect the flexi pipe to the waste pipe in the floor and lower bath into position. Check for any signs of a leak - if none fix the bath to the floor through the holes provided in the base.

plumbworld
Big brands, small prices.

Pdf Supplied By <http://www.plumbworld.co.uk/>