

AD118941

# MODULAR SHOWER CURTAIN ROD



## 4 WAYS TO FIT

- One kit makes 4 shapes -ideal for both cubicle or over bath showering
- Use as standard size or cut to size

**STRAIGHT:** 1735mm

**U-SHAPED:** 900 x 930mm

**L-SHAPED:** 900 x 900mm

**LARGE L-SHAPED:** 900 x 1760mm

## FIXING PACK CONTENTS

- (A) Fixing Screws x 3
- (B) Wall Plugs x 3
- (C) Cavity Wall Plugs x 3

## TOOLS REQUIRED

- Drill
- 5.5mm masonry drill bit (5.5mm ceramic drill bit optional)
- Cross-head screwdriver
- Spirit level

## KEEP DIY TOOLS OUT OF THE REACH OF CHILDREN





## EASY TO INSTALL

We recommend that two people install this product.

1. Assemble the rod to suit the location, trimming to length if required with a hacksaw. Always trim the end of the rod which fits into the wall bracket.
2. Using the wall bracket as a template, mark the position of the screws and drill the holes to a depth of 30mm using a 5.5mm masonry drill. Check the wall brackets are level prior to drilling.
3. Insert the wall plugs flush to the surface of the wall and secure the wall brackets into position. If fitting to a tiled surface, the wall plugs should be inserted below the surface of the tile to avoid cracking.
4. Fit the assembled rod into the wall brackets. Please note the decorative covers need to be placed on the rod before the rod is located into position.
5. Slide the decorative covers over the wall brackets to complete the assembly.

## GENERAL SAFETY ADVICE

- Always take care when using an electric drill, particularly in the bathroom. Always check for hidden cables and pipework before drilling. Always use a residual current circuit breaker (RCCB) when using mains powered tools and take extreme care if there is any water in the working area.
- Always wear suitable eye protection when drilling.
- If the product is to be fitted on a ceramic tiled wall, a ceramic drill bit should be used. Do not drill mounting holes in the grouted area between tiles. Mask the area around the hole with tape before drilling to prevent damage to the tile.
- Clean with a damp cloth.
- Do not use abrasive or chemical cleaners.
- Do not use the rod or curtain as a support when showering.

<b>4 WAYS</b>	<b>U-SHAPED</b>	<b>L-SHAPED</b>
		
	900 x 930mm	900 x 900mm
	<b>LARGE L-SHAPED</b>	<b>STRAIGHT</b>
		
	900 x 1760mm	1735mm

