



Midas Basin monobloc installation guide addendum

The Midas Basin monobloc tap now features two connections for the clamp bolts. An extra clamp bolt is supplied. Two extension pieces are also supplied for connection between the tap body and the flexible hoses (the above extra parts are not shown in components). Please follow the instructions below in place of instruction 3 & 4 provided:

3. Secure the extension tubes into the tap body inlets and tighten using a suitable tool, taking care not to over tighten. Fit the flexible hoses into the extension tube inlets and again tighten using a suitable tool, taking care not to over tighten.
4. Place the clamp bolts into position within the tap body and secure using a suitable tool.

If you have any queries regarding the installation of this product please contact the customer helpline on 01959 560010.

Check out our full range of Bathroom Taps

Contemporary Bathroom Taps

Traditional Bathroom Taps

Waterfall Bathroom Taps

Basin Taps

Bath Taps

Bidet Taps

Luxury Mira Aspects Taps

Mira Honesty

Mira Evolve

Mira Precision

Mira Comfort

Mira Revive

Mira Fluency

Don't forget these amazing tap cleaning and care products

Cramer Tap Cleaner

Cramer Chrom Star Chrome Polish

plumbworld
Big brands, small prices.