

### **BATHROOM FURNITURE CARE GUIDE**

- Should any of your items have a defect, please do NOT install as returns will not be accepted once fitted.
- 2. We advise that you use a qualified person to install your units, as any issues relating to poor fitting will not be accepted by the supplier.
- 3. You have purchased a handmade and in some cases hand painted product. Therefore, you may see some slight imperfections which the supplier may deem as acceptable.
- 4. This product is water resistant but NOT waterproof. On no account should any spillages or splashes, even water, be allowed to lie on any surface. All spillages and splashes should be wiped dry, failure to do so may shorten the life expectancy of the product and invalidate any guarantees.
- 5. Please avoid direct sunlight as this will cause the painted surfaces to dis-colour.
- 6. Due to motion in transit, the cabinet doors and drawers may need to be adjusted after installation.
- 7. Floor Standing units must be fitted back to the wall through the backrail using suitable fixings (not supplied).

Please note that although these units have been designed to give years of pleasure and satisfaction, you will help maintain the original beauty of your bathroom by following these guide lines.

#### Painted Doors

Use a cleaning product not containing aggressive substances like acetone, alcohol, bleach ... as those components could seriously damage the surface of your furniture. The best would be to use a soft cotton or micro fibre cloth with only water and soft soap (containing a maximum 1% of liquid soap)

#### **Painted Carcase Components & Bath Panels**

Do not use polish on any surfaces. A damp cloth with soapy water will clean off most marks or spills. Bleaches, scouring pads and multi-surface cleaners must not be used.

#### **Drawers, Runners, Door Hinges**

These should be wiped out with a damp soapy cloth and wiped dry with a soft cloth as necessary. The runners and hinges are lubricated and should not be cleaned with a degreasing agent as this will affect the action of the moving parts. Never lean on partially or fully opened doors and drawers in order to gain access to the units. The hinges are specified to adequately support the weight of the door. It is advised that once the furniture has been installed you should check every six months that all screws on the hinges are tight.

#### **Marble Worktops**

Although the worktop is hard wearing, sharp objects will scratch and excessive heat will scorch the surface. Care should be taken not to drop any heavy objects onto the worktop as the surface may crack. For cleaning, a damp soapy cloth will clean off most spills. Bleaches, scouring pads and multi-surface cleaners should must <u>not</u> be used. Corrosive liquids and make-up should be wiped off immediately. On no account should any spillage, even water, be allowed to lie on the surface.

#### **Temperature and Humidity**

Avoid excessive change in temperature and humidity. Always try to ensure adequate ventilation.

### **Spillages and Splashes**

On no account should any spillages or splashes, even water, be allowed to lie on any surface. All spillages and splashes should be wiped dry, failure to do so may shorten the life expectancy of the product and invalidate any guarantees.


#### Regulations

If it is your intention to remove and replace your bathroom fittings with "like for like" units, then this is classed as "non regulated" and no building regulations would be required. However, building regulation approval may be required if the bathroom refurbishment involves altering the drainage or the internal layout within the dwelling to accommodate the new fitting such as a second bathroom. In this instance, we would advise you to contact the Building Control Department at your local authority to discuss the need for a formal building regulation application. Macerator - Current building regulations specify that a sanipump smallbore system can be fitted in a dwelling where there is also a normal gravity discharge W.C. It should not be the only W.C. facility. Electrical - Remember that double pole isolating switches are required for all electrical points apart from special razor sockets. All work must conform to BS7671: 2008 the current I.E.E. Regulations.

The company reserves the right to continually evolve its product lines without notification.

The company will not accept any liability regarding specification changes and their consequences unless previously quoted by the company in writing.

### STANDARD BATH PANEL FITTING INSTRUCTION



- 1. Measure from the underside of the bath rim to the floor to establish the height of the bath panel required.
- 2. Drill equally spaced holes along the plinth and screw to the bottom edge of the main panel at the desired height.
- 3. It is advisable that you build a frame or fit battens along the floor and down the wall sides to support the panel.
- 4. When an end panel is used, it may be necessary to trim the panel & plinth to length. any trimming should be done at the wall end to ensure that the finished edge is at the visible corner.the front and end panels are fastened together using the screws & corner brackets provided.
- 5. Any cut or trimmed edges must be sealed against water ingress. it is also advisable to seal all the outer edges of the panels and in particular the underside of the bath lip where the panel meets.

# **Check out our full range of Bathroom Suites**

Bathroom Suites By Range

**Cloakroom Suites** 

**Toilets** 

Bathroom Sinks / Wash Basins

**Bidets** 

**Baths** 

### Wide variety of toilets

**Close Coupled Toilets** 

Wall Hung Toilets

**Back To Wall Toilets** 

Furniture unit toilets

## **Huge Selection of Baths**

**Acrylic Baths** 

Steel Baths

Shower baths

Freestanding baths

Small baths

Corner baths

Whirlpool baths

# Don't forget the important bathroom suite extras

Bath panels

Toilet seats

