



Installation Guide



1. Insert the 15mm pipe into the valve.



2. Put the Pipe Shroud over the 15mm pipe.



3. Insert decorative cover, parallel on both sides.