

Manual Installation

Plumbing Systems and Water Pressure

All products are suitable for all UK Water Authority supply pressures. If the product is installed at low pressure (tank fed) then the minimum height from the outlet of the shower head to the underside of the cold tank should be 1.8 metres to ensure adequate performance.

This product should be installed in accordance with the current Water Regulations. Any claims that may arise will be dealt with on the basis that isolating valves are fitted.

Water Pressure:

We recommend a minimum water pressure of 0.5 Bar and a maximum of 5 Bar to ensure efficient operation of your product.

Cleaning/General Care

Chrome and matt black plated finishes should be cleaned with warm water and a soft cloth, rinsed and then immediately buffed with a dry soft cloth. Under no circumstances must any aggressive or abrasive cleaning agents be used. The use of any abrasive agents or materials will invalidate the guarantee.

Round Thermostatic Valve & Kit Chrome

Installation Guide

- 1.Put the thermostatic valve into the cold and hot inlet tube by S connector and tighten it.
- 2.Put the rail tube bottom in to the thread upside of thermostatic valve and measure the rail and confirm the assemble holes.
- 3.Slide the bracktt into the standpipe,then Insert the upper tube into the standpipe and tighten it.
- 4.Put the plastic insert into the set holes and lock the cover(1) by bolt.
- 5.Put the connect bar(1) into the cover(1) and lock it by wrench.
- 6.Screw the top shower head to the top of the rail.
- 7.Connect the hose to the screw of downside of thermostatic valve and the other side to the hand shower.
- 8.Then put the handshower into the holder.

