Manual installation

Plumbing Systems and Water Pressure

All products are suitable for all UK Water Authority supply pressures. If this product is installed at low pressure (tank fed) then the minimum height from the outlet to the underside of the cold tank should be 1.8 metres to ensure adequate performance.

This product should be installed in accordance with the current Water Regulations. Any claims that may arise will be dealt with on the basis that isolating valves are fitted.

Water Pressure:

We recommend a minimum water pressure of 0.5 Bar and a maximum of 5 Bar to ensure efficient operation of your product.

Cleaning/General Care

Chrome and Gold plated finishes should be cleaned with warm water and a soft cloth, rinsed and then immediately buffed with a dry soft cloth. Under no circumstances must any aggressive or abrasive cleaning agents be used. The use of any abrasive agents or materials will invalidate the guarantee.

Overflow Bath Filler And Waste

Installation Guide

Prior to installation, please check that your plumbing system is adequate and that all pipes have been sufficiently flushed through.

1. Remove the hex cap from the overflow body, then connect the inlet pipe.

2. Unscrew the overflow cover from the overflow body, insert the body into the bathtub hole, and screw back the overflow cover.

3. Remove the drain cover, decorative cover and one gasket from the drain body; connect the drain body to the bathtub drain hole.

4. Fit the drain decorative cover and drain cover onto the drain body.

