

# **INSTRUCTIONS FOR KNOCKING THROUGH THE TAP** **HOLE**

You will need:

A 10mm Pin or Centre Punch  
A Claw Hammer  
Safety Goggles & Gloves

**It is highly recommended that safety goggles and gloves are worn when knocking through the tap hole.**

Position the pin punch on the surface of the sink over the centre of the part-drilled hole (please note that the red dot labels are for guidance only and do not give the exact centre of the tap hole).

Gently tap the punch with a claw hammer until a hole is punched through, and then continue tapping out the excess from around the hole, ensuring any rough or sharp edges are removed.