


INSTALLATION MANUAL


Eastbrook 























Eastbrook Road, Gloucester GL4 3DB



Technical Helpline: 01452 317890

email: technical@eastbrook.co.uk







1  D6x30 8Pcs	2  ST4X30 16Pcs	3  ST4X12 12Pcs	4  RF-6Y01 8Pcs	5  RF-6W01 2Pcs	6  1908mm 2Pcs	7  RF-6Z02 2Pcs
8  RF-6Z02 2Pcs	9  RF-6X04 2Pcs	10  RF-6X04 2Pcs	11  RF-6X02 4Pcs	12  RF-6Y03 2Pairs	13  RF-6Y05 8Pcs	14  RF-6Y02 4Pcs
15  RF-6X03 4Pcs	16  RF-6W22 4Pcs	17  A+B CRF-6Z01 1Pairs	18  RF-6Y07 2Pcs	19  ST4X8 4Pcs	20  RF-6C1 2Pcs	21  RF-6Y12 2Pcs
22  RF-6Y13 2Pcs	23  RF-6Y04 4Pcs	Tools:				
				 2 mm	 Ø6mm	 Ø3.2mm
						





3







4






5



6



7



7-1

Ø3.2mm
0-20mm

7-2






3x8
4x8

7-3

20x2


7-4

8



Care Instructions:

Do not use your shower enclosure within 24 hours of assembly .
Do not use caustic cleaning products or abrasive material when cleaning your shower enclosure.



Eastbrook

Eastbrook Road, Gloucester GL4 3DB

Technical Helpline: 01452 317890

Email: technical@eastbrookco.com

Cleaning and Maintenance of Shower Enclosures

Do not clean the shower enclosure with irritant detergents such as alcohol, bleach or other chemical cleaners.

Only clean with mild soapy water or a proprietary cleaner where the label advises it is suitable for the materials the enclosure is constructed from. Test on a small area first.

For treating limescale we would recommend distilled vinegar in a half and half solution with water.

Following installation should you find that there is a notable noise when the glass door moves you may add a small amount of silicon lubricant onto the roller wheels and tracks, hinges or clips.

It is the responsibility of the product owner to maintain the product as recommended above. Also, to check for parts which have broken or become loose to protect against failure of the enclosure.