


EN Instructions for use / assembly instructions



Vernis Shape 70

71560XXX / 71566000 / 71567XXX /
71596000

Vernis Shape 70 CoolStart


71593XXX

Vernis Shape 100

71561XXX / 71568000 / 71569XXX /
71597000

Vernis Shape 100 CoolStart

71594XXX



Vernis Shape

71211XXX



Safety Notes

- △ Gloves should be worn during installation to prevent crushing and cutting injuries.
- △ The product may only be used for bathing, hygienic and body cleaning purposes.
- △ The hot and cold supplies must be of equal pressures.

Installation Instructions

- Prior to installation, inspect the product for transport damages. After it has been installed, no transport or surface damage will be honoured.
- The pipes and the fixture must be installed, flushed and tested as per the applicable standards.
- The plumbing codes applicable in the respective countries must be observed.
- The drain valve must only be used as intended. It is not allowed to attach other objects to the drain valve, for example a semi-pedestal.
- If the instantaneous water heater causes problems or if you wish to increase the water flow, the EcoSmart® (flow limiter) located behind the aerator can be removed.

Technical Data

This mixer series-produced with EcoSmart® (flow limiter)

Operating pressure:	max. 1 MPa
Recommended operating pressure:	0,1 - 0,5 MPa
Test pressure:	1,6 MPa
	(1 MPa = 10 bar = 147 PSI)
Hot water temperature:	max. 60°C
Thermal disinfection:	70°C / 4 min

The product is exclusively designed for drinking water!

Symbol description



Do not use silicone containing acetic acid!



Adjustment (see page 36)

To adjust the hot water limiter. Using a hot water limiter in combination with a continuous flow water heater is not recommended.



Dimensions (see page 40)



Flow diagram (see page 41)

- ① with EcoSmart®
- ② without EcoSmart®



Spare parts (see page 38)

- XXX = Colors
- 000 = Chrome Plated
- 670 = Matt Black

Special accessories (order as an extra)



- special tool #58085000 (see page 32)



- Installation putty (see page 33)



Cleaning (see page 37)
















Operation (see page 42)







- Hansgrohe recommends not to use as drinking water the first half liter of water drawn in the morning or after a prolonged period of non-use.
- After periods of prolonged non-use, but at least every third day, the fittings must be opened with the handle in hot and cold position to prevent stagnation in the connecting lines. Let the water run until the water temperature is constant.
















Test certificate (see page 44)












Vernis Shape

71211XXX






Vernis Shape 70

71560XXX / 71566000 /
71567XXX / 71596000


Vernis Shape 70 CoolStart 71593XXX



Vernis Shape 100


71561XXX / 71568000 /
71569XXX / 71597000

Vernis Shape 100 CoolStart 71594XXX



Vernis Shape

71211XXX



Vernis Shape 70

71560XXX / 71566000 / 71567XXX / 71596000




Vernis Shape 100

71561XXX / 71568000 / 71569XXX / 71597000

Vernis Shape 71211XXX

Vernis Shape 70 CoolStart 71593XXX

Vernis Shape 100 CoolStart 71594XXX





Vernis Shape 70

71560XXX / 71566000 / 71567XXX / 71596000

Vernis Shape 70 CoolStart

71593XXX

Vernis Shape 100


71561XXX / 71568000 / 71569XXX / 71597000

Vernis Shape 100 CoolStart

71594XXX

Vernis Shape

71211XXX





Vernis Shape 70






71560XXX / 71566000 / 71567XXX /
71596000

Vernis Shape

71211XXX

Vernis Shape 100

71561XXX / 71568000 / 71569XXX /
71597000





Vernis Shape 70 CoolStart

71593XXX

Vernis Shape 100 CoolStart

71594XXX

