





Ordering spares / Ersatzteil - Regelung / Pièces de rechange / Parti di ricambio / Lista de recambios / Onderdelen bestellen (NL/B) / Κωδικοί Ανταλλακτικών / Bestilling af reservedele / Beställning av reservdelar / Bestilling av reservedeler / Резервни части / Запчасти / Części zapasowe / Piese de schimb / Rendelhető alkatrészek / Запасні частини / Резервни делови / Резервни делови / Atsarginių dalių / Tellitavad varuosad / Rezerves daļas / Náhradní díly / Náhradné diely / Yedek parça siparişi / Nadomestni deli

XX = AA, AD,

- 1 - B 961718 XX
- 2 - B 960473 XX
- 3 - B 961438 XX
- 4 - B 961374 NU
- 5 - A 861181 NU
- 6 - B 961491 NU
- 7 - B 961728 NU
- 8 - A 962708 XX
- 9 - B 961596 NU
- 10 - A 964520 NU
- 11 - A 963600 XX
- 12 - B 960845 NU
- 13 - B 961947 NU






Ideal Standard


CERAPLAN







07.2025 / B565155

B D245 ..







Ideal Standard International NV
Corporate Village – Gent Building
Da Vincilaan 2
1935 Zaventem
Belgium
www.idealstandard.com





	P	bar		MAX. 10				Q (3 bar)
	T	°C		MAX. 80				l/min
								3,1



			0	1	2	3	4	5
			°C	°C	°C	°C	°C	°C
P	50°C	15°C	50	49	44	40	35	33
	65°C	15°C	65	63	57	50	44	40
	85°C	15°C	85	83	74	64	56	50

