

Additional storage tanks must be the same capacity as the main TankBoost unit.

The tanks must be located next to each other and on the same level.

The total volume of stored water must not be more than will be used in a single day.

The supplied tank connector kit should be used to link the tanks.