

TYPE 11 & TYPE 22 FLAT PANEL RADIATORS Instruction Manual

INSTALLATION GUIDE





INSTALLATION

This product must be installed by a fully qualified engineer.

Please consider using an Eastbrook Valve Set – this will ensure that your radiator looks its best with matching radiator valves.

• On commissioning, flush the central heating system thoroughly using a proprietary solution to ensure that aggressive substances such as fluxes and manufacturing residue, from which internal surfaces of your radiator can sustain irreparable damage – are removed. It is further recommended that an appropriately approved corrosion inhibitor be subsequently added to the heating system in order to protect the radiator and other parts of the central heating system to promote extended operating lifespan.

MAINTENANCE

- From time to time it is advisable to clean your towel rail with a warm damp cloth. Never use any form of abrasive cleaner or chemical.
- Corrosion inhibitor must also be regularly maintained, please consult your engineer for details.

WARRANTY

Your Flat Panel Radiator is fully warranted for five years in respect of defective materials and workmanship and subject to installation being carried out by a qualified engineer in accordance with good practice and corrosion inhibitors being regularly maintained.

IMPORTANT

- Maximum working pressure of this radiator is 4 bar.
- This radiator is to be used on Domestic Central Heating systems only.

 (Not suitable for use on direct hot water systems) Please consult your engineer or supplier.

Eastbrook Eastbrook Road, Gloucester GL4 3DB
Technical Helpline: 01452 317890
Mon - Fri / 8am - 5pm
Email: technical@eastbrookco.com