

Alice 2
fixed showerhead



INSTALLERS PLEASE NOTE THESE INSTRUCTIONS ARE TO BE LEFT WITH THE USER

54939 ALICE FIXED SPRAYHEAD

INTRODUCTION

Your shower is supplied with a fixed sprayhead, which is single mode with a rub clean head.

WARNING!

Do not use abrasive or solvent cleaning fluids. The showerhead should be cleaned using a soft cloth and warm water.

CLEANING

Before cleaning, turn off the unit at the mains supply to avoid the shower being accidentally switched on.

IT IS IMPORTANT TO KEEP THE SPRAYHEAD CLEAN TO MAINTAIN THE PERFORMANCE OF THE SHOWER. The hardness of the water will determine the frequency of cleaning. For example, if the shower is used every day in a very hard water area, it may be necessary to clean the showerhead on a weekly basis.

To clean the nozzles simply rub your thumb over them.

DO NOT use a pin or similar to poke the holes otherwise the efficiency of the shower spray will be impaired.

In extreme cases, remove the sprayhead and leave to soak overnight in a mild proprietary descaler. Make sure all traces of scale are removed and thoroughly rinse in clean water afterwards.

Before refitting the sprayhead, flush any debris out of the hose.

SPARES

Sprayhead

88600023

Please refer to shower installation and operating instructions for service details. E&OA.