

ENlight®

Thermostatic Electric Shower

Quick-Start User Guide



For a cleaner conscience



60427010A - January 2025


Heater
Button

ECO
Button

START/STOP
Button

Temperature
Selector Knob

The temperature selector knob can be adjusted at any time to adjust the showering water temperature.



Display

ECO LED

Fault LED

Light Bar

TRITON



When the electricity supply to the shower is switched on , the Standby animation will appear on the Light Bar. Press the START/STOP Button to switch the shower on.

Note: The shower can also be started with the ECO Button to start in ECO Mode, or with the Heater Button to start the shower with the heat off.



The showering water temperature is shown on the display. The Light Bar gradually fills up, and becomes completely filled after 5 minutes. An animation occurs on the Light Bar, repeating and increasingly more frequent as time elapses. After 20 minutes (by default), the shower will automatically enter Phased Shut Down.



Press the ECO button from Standby to start the shower in ECO Mode. The Light Bar will count down for 5 minutes (by default), after which the shower will automatically enter Phased Shut Down. ECO Mode can be cancelled by pressing the ECO button; the regular timer settings will apply.



Turn the Temperature Selector Knob anti-clockwise to make the showering water cooler. Turn it clockwise to make the showering water hotter.

Press the Heater Button to run the shower at ambient water temperature. This will be indicated on the display, and the Light Bar illumination will turn blue.




Press the START/STOP button whilst showering to start the Phased Shut Down routine, this purges the heater can of hot water before returning the shower to Standby. The shower duration will be shown on the display during the Phased Shut Down routine.

ENlight® Product Support



Scan the **QR code** below for access to ENlight® Product Support.



tritonshowers.co.uk/enlightsupport

To register your new ENlight® shower, as well as see our latest service policy and contact details, visit

tritonshowers.co.uk

or call us on **02476 372 222**.

If an error is detected, the Light Bar will show a red animation and the fault or fault number will be shown on the display.

Please refer to the installation instructions for further information on faults.