



- A** x 1
 - B** x 1
 - C** x 4
 - D** x 4
- *

GB
Wall plugs and screws are not included. Use fixing devices (sold separately) that are suitable for the type of wall in your house.

