

Temperature Setting

1

Turn flow handle to 'on' position, letting temperature stabilise.

2

Remove temperature handle

3

Turn cartridge spindle clockwise to decrease the temperature.

4

Turn cartridge spindle anti-clockwise to increase the temperature.

5

Replace temperature handle

Maintenance - Cartridge Cleaning

1

Using the wall mount, isolate both shower inlets before carrying out any maintenance.

2

Remove temperature and flow handles

3

To remove thermostatic cartridge remove temperature stop and insert cartridge tool (not included) and use an adjustable spanner to unscrew the retaining nut.

4

Unscrew retaining nut to remove diverter cartridge.

5

Remove O-rings and soak all components in de-scaler and wash off in clean water. Examine all seals and replace if needed. Use WRAS approved silicon based grease on all seals.

6

Reverse steps 5-2 to reinstall the valve, cartridge and handles.

7

Turn the water supply to the shower back on.

Servicing Intervals

To reduce the build up of limescale and to ensure this shower works to its maximum performance we recommend this shower is serviced every 6-12 months depending on the hardness of your water.

REMEMBER
To service your product!

Spare Parts

To replace any spare parts for your shower, why not scan the QR Code or visit www.bristan.com and search for your product.

Riser Installation

1

Using a spirit level to ensure the riser is positioned correctly, use the assembled riser to mark the desired position of the brackets.

2

Disassemble bracket, align on the wall in the correct position and mark location of holes to be drilled.

3

Secure bracket to wall using screws and plugs provided.

4

Attach shroud and secure riser to bracket by tightening grub screws.

5

Push the riser rail into the bracket and screw to tighten.

6

Attach handset and fixed head. To adjust the riser pull the top cap up and use a hexagonal spanner to loosen the nut. Pull rail to desired position then tighten the nut and pull cap back down.

Troubleshooting		
Symptom	Cause	Remedy
No flow or low flow rate	partially closed isolation valve.	Open isolation valve.
	Instantaneous water heater cycles on and off as flow rate or pressure is too low.	Increase water flow rate or pressure through system.
	Head of water is below the minimum distance required.	2 meters minimum required.
	Hot or cold water being drawn off elsewhere causing pressure changes or instantaneous boiler temperature changes.	Do not use other water outlets when using the taps.
	Airlock or partial blockage in the supply pipework.	Flush through pipework to ensure removal of debris and any airlocks.
Water dripping from shower	This is normal for a short time after using the shower.	This is caused by residual water tension, the build up of water in the shower.
	If water continues to drip, possibly due to the cartridge	Remove cartridge and clean, refer to 'Maintenance' section before starting any maintenance.
Shower does not turn on	Closed isolation valve.	Open isolation valve.
	Mains water supply turned off.	Turn on mains water supply.

At Bristan, we want to make things as easy as possible for our customers. That's why we offer solid guarantees on all our products, effective from the date of purchase, to give you peace of mind.

Your guarantee starts from the purchase of your product, but you can still benefit from registering it for easier identification in the unlikely event of a manufacturing fault, please visit www.bristan.com/register

For any other queries, please call Customer Service on 0330 026 6273 where our expert team of advisors will be able to offer you any help and advice.

For full guarantee terms and conditions visit www.bristan.com/service-centre/guarantees

Bristan Group Ltd.

UK: Bristan Group, B78 1SG.
EU: Masco Europe S.à.r.l., 14 Rue Strachen
6933 Mensdorf, Luxembourg.

Customer Service: +44330 026 6273
Web: www.bristan.com
Email: enquire@bristan.com

A Masco Company

BRISTAN