

SHOWER RAIL

L Shape Rail Installation.

Tools required to complete the installation.

- Electric Drill with 8mm masonry drill bit 
- Suitable Hex Screwdriver 
- Masking tape to ensure tiles are not damaged when drilling 
- Stainless Steel Pipe cutter or suitable hacksaw 
- Spirit level to get rail level 
- Tape measure 



Installation instructions

- Measure up from the **inside base of the bath approximately 190 cm** and make a horizontal line where you would like bracket **"a"** to be positioned

(This is so the rail and new curtain fit perfectly as shower curtains are normally 180cm drop from shower rail)

- Decide on the desired length and height of your shower rail and using a pipe cutter or hacksaw cut the stainless steel rail to size.

(Tip - Rails should be slightly shorter than the length of your bath)


- Assemble the corner piece and tighten the two grub screws with the allen key provided.




- Hold the L shaped rail up against the walls and ceiling as per Diagram 1 and mark the position of the point where the long tube touches the wall on your newly marked horizontal line with a pencil **"a"**.

Note. You will need an 8mm masonry drill bit to go through your tiles


- Fix masking tape to the area where you will fix the first bracket and carefully mark and drill the three holes, then add the rawplugs and fix bracket to wall.
- Insert assembled rail into the wall bracket **"a"** then check that the rail is level using a spirit level and mark position of the second bracket **"b"** on ceiling.
- Carefully mask the ceiling off, drill the holes and add the rawplugs (Note. You may need extra bracing in your ceiling space to screw into)
- Slide remaining bracket onto the shorter rail and then push the opposite end of the rail into bracket **"a"**. Slide second bracket to ceiling and fix **"b"**.
- Tighten the allen screws on both brackets with the allen key provided to finish your installation.



- Tape up area with masking tape
- Mark & drill holes using an 8mm masonry drill
- Add rawplugs & fix bracket to tiled wall and ceiling



- Ensure rod is level and straight
- Mark new bracket and repeat above procedure then fix rail in place



plumbworld
Big brands, small prices.

Pdf Supplied By <http://www.plumbworld.co.uk/>