

# Installation Guide for Crescent Rod

## 1.) Your Package Will Contain:

Allen key

Decorators rawplugs

Raw plugs



### 1. Two assembled brackets each consisting of:

1. 1x Wall plate
2. 1x Swivel connector
3. 2x Retaining screws

### 2. One Sealed Hardware Package:


1. 1x Allen Wrench
2. 4x Wood Screws
3. 4x Rawplugs (for tile)
4. 4x Decorator rawplugs (for sheetrock/drywall)
5. 2x set screws in a small plastic bag
6. One Curved Crescent Shower Rod™
7. Instructions

**Note. Make sure the walls can support Crescent Rod before purchasing it is suggested that crescent rod should not be mounted on acrylic or fibreglass type walls without consulting customer service.**

## 2.) The Crescent Rod™ Mounting Instructions


### For 180cm Standard Bath

Mount rod approximately 3" inside the point a straight rod is normally mounted.  
The midpoint of the rod should extend several inches past the outside rim of the tub.



### For Corner Bath

Depending upon the style of the bath, this is how it will look when fitted.





### 3.) The Crescent Rod™ Rawplug Instructions

Each screw must be secured to the wall using the appropriate rawplug / screw.

#### **Plaster Board:**

Use a decorator's rawplug here. Drill a small pilot hole through the wall to determine if there is stud beneath your mark. If not, insert #2 Phillips screwdriver into anchor. Press into hole while turning the rawplug clockwise until seated flush with wall. Repeat for each screw.

#### **Tile:**

Use rawplug. Using a glass/tile 1/4" drill bit, drill holes where marked. Blow the clean of dust. Tap rawplug into hole until flush with surface.

**Do not mount on acrylic or fibreglass type walls without consulting customer service!**

### 4.) Installation Instructions

1. Read mounting instructions for proper rod placement.
2. Assemble Crescent Rod. Hand tighten remaining screws. Do not use setscrews at this time.
3. Measure: Hold rod up to desired position, one person at each end, to check height and location. Be sure that rod is level with a pencil lightly score marks the top and bottom of the wall plate. Set rod down.
4. Remove retaining screws. Separate the wall plates from the rod. Leave the Swivel connectors on rod.
5. Place wall plates back on wall at pencil marks.
6. Mark screw holes at 12 and 6 O'clock positions. Set wall plate aside.
7. Read anchor instructions carefully. Drill screw hole as marked. Install 4 rawplugs unless a hole is on a stud wall.
8. Mount wall plates. Screw into anchors.
9. Place rod, with swivel connectors attached, into wall plates. Screw in retaining screws. Tighten.
10. Adjust rod. Be sure that each end is into connectors far enough for setscrew contact.
11. Insert and tighten setscrews with the allen key.



### **Adjustments**

The Crescent Rod is designed to slide back and forth in the swivel connector adjusting for variations in the span between the walls.

### **Hardware:**

The wall plates and swivel connectors can go on either wall (i.e., no left or right bracket).

Note: The swivel connector can be inserted into the wall plate with the setscrew facing up or down. It is recommended that the setscrew always face up!

When on top, the setscrew helps keep the curtain ring close to the wall.

## **5.) Customer Service**

The Crescent Rod is designed to fit the most common 5ft and 6ft baths. Occasionally, because of remodeling or non-standard tub size, you may encounter these situations:

### **1. Rod too Long:**

If the rod is too long, the end can be cut with a tube cutter or hacksaw. Be sure to remove equal portions from each end to keep the contour centered.

### **2. Rod too Short:**

If the span between the end of walls is greater than 59 1/2" you will need to order a larger 6ft rod.

**plumbworld**  
**Big brands, small prices.**

Pdf Supplied By <http://www.plumbworld.co.uk/>