

Exposed / Concealed Shower Valve

Plumbing Systems and Water Pressure

All products are suitable for all UK Water Authority supply pressures. If the valve is installed at low pressure (tank fed) then the minimum height from the outlet of the nozzle to the underside of the cold tank should be 2.0 metres to ensure adequate performance.

This valve should be installed in accordance with the current Water Regulations. Any claims that may arise will be dealt with on the basis that isolating valves are fitted.

Water Pressure:

We recommend a minimum water pressure of 0.5 Bar and a maximum of 5 Bar to ensure efficient operation of your product.

Cleaning/General Care

Chrome and Gold plated finishes should be cleaned with warm water and a soft cloth, rinsed and then immediately buffed with a dry soft cloth. Under no circumstances must any aggressive or abrasive cleaning agents be used. The use of any abrasive agents or materials will invalidate the guarantee.

Customer Care Helpline

Telephone: 01490 266060


Email: technical@plumbworld.co.uk

Installation Guide

Follow these instructions before fitting the valve detailed in this guide.

Prior to installation, please check that your plumbing system is adequate and that all pipes have been sufficiently flushed through.

1. Turn off the mains cold water supply. The mains stopcock is usually found where the supply enters the building.
2. It is also recommend that any hot water heating systems are turned off.
3. Drain the hot and cold water systems. To ensure complete drainage, open all taps.



Concealed installation

4. Determine the fixing position for the product and make a recess in the wall to house the shower valve. The depth of the recess should be from 42mm to 80mm below the wall surface to fit the cover plate correctly.
5. Insert the valve into the wall recess, then mark fixing points with the mounting lugs that are cast on the valve body. Pull the valve out and drill suitable length holes at the marked positions. Use supplied plugs and screws to secure the valve.
6. Now the shower valve body is securely mounted to the wall. Prior to installation and connecting, make sure the

pipes are thoroughly flushed to remove any debris etc.

Attention: Failure to do this will impair the flow of water.

7. The plumbing connections should then be made to the hot & cold water inlets which are clearly marked. Hot water inlet to be connected with hot supply on the left of the valve, cold water inlet to connected with cold supply on the right of the valve.
8. Make the plumbing connection to the water outlet. This will take the water to the chosen auxiliary product (shower kit) you have selected to run with this shower.
9. Turn on the water supply. Check that there is no leakage.
10. Slide the plate into position over the lock sleeves, and fit up against the finished wall surface.
11. Fit the chrome control lever. Hold the handle firmly in position and tighten the grub screw with supplied Allen key.

Exposed installation

12. Determine the fixing position for the product and mark on the wall.
13. Loosen the grub screws at side of the valve bottom, take out the base plate.
14. Fix the base plate on the wall with fixing screws/plugs.
15. Connect the pipework to inlets making sure hot water is connect to the left side.
16. Fix the valve body to the base plate, making sure the cover plates are connected.
17. Turn on the water supply. Check that there is no leakage.
18. Fit the chrome control lever. Hold the handle firmly in position and tighten the grub screw with supplied Allen key.

Check out our full range of Showers

Electric Showers

Digital Showers

Mixer Showers

Power Showers

Smart Showers

Shower Towers

From Top Shower Brands

Mira Showers

Aqualisa Showers

Triton Showers

Gainsborough Showers

Shower Pumps can upgrade your showering experience even more

Stuart Turner Shower Pumps

Salamander Shower Pumps

Grundfos Shower Pumps

plumbworld
Big brands, small prices.