

## Plumbing Systems and Water Pressure

All products are suitable for all UK Water Authority supply pressures. If the taps are installed at low pressure (tank fed) then the minimum height from the outlet of the nozzle to the underside of the cold tank should be 2.0 metres to ensure adequate performance.

These taps should be installed in accordance with the current Water Regulations. Any claims that may arise will be dealt with on the basis that isolating valves are fitted.

### Water Pressure:

We recommend a minimum water pressure of 0.5 Bar and a maximum of 5 Bar to ensure efficient operation of your product.

### Cleaning/General Care

Chrome and Gold plated finishes should be cleaned with warm water and a soft cloth, rinsed and then immediately buffed with a dry soft cloth. Under no circumstances must any aggressive or abrasive cleaning agents be used. The use of any abrasive agents or materials will invalidate the guarantee.

### Customer Care Helpline

Telephone: 01490 266060

Email: [technical@plumbworld.co.uk](mailto:technical@plumbworld.co.uk)

## Installation Guide

*Follow these instructions before fitting the tap.*

**Prior to installation, please check that your plumbing system is adequate and that all pipes have been sufficiently flushed through.**






1. Turn off the mains cold water supply. The mains stopcock is usually found where the supply enters the building.
2. It is also recommend that any hot water heating systems are turned off.
3. Drain the hot and cold water systems. To ensure complete drainage, open all taps.
4. Loosen the connections.  
There are two possible situations:
  - There are two supply pipes, each end with a compression fitting
  - There are two shut-off valves in the pipes under the sink.

In both cases, loosen and disconnect the joints with an adjustable wrench. Remove the old tap.

5. Fit the new tap. The new tap will have a tube with an external screw thread at its base, push the tube through the hole in the kitchen sink or worktop. Push the retaining plate and washer over the tube, fit the nut and tighten it with an adjustable wrench

or water pump pliers. Check that the tap is facing in the right direction. If you've installed a new kitchen sink or composite worktop you'll have to drill a new hole of the right diameter for the mounting tube of the tap. Use a hole saw of a suitable type for the material of the sink or worktop.

6. Water supply pipes there are two flexible braided hoses supplied with the tap which should be screwed into the base of the tap, for the hot and cold water supplies. These are made of soft, flexible material and have a diameter of 10 mm. Next, fit the unattached ends of the flexible supply pipes to the ends of the pipes coming out of the wall using compression fittings. The hot water is usually at the left.
7. Check all the connections are secure.
8. Open the main water valve and check for leaks.



## **Check out our full range of Kitchen Products**

### **Kitchen Sinks**

Stainless Steel Kitchen Sinks

Granite Composite Kitchen Sinks

Glass Kitchen Sinks

Ceramic Kitchen Sinks

Franke Kitchen Sinks

### **Kitchen Taps**

Contemporary Kitchen Taps

Traditional Kitchen Taps

Franke Kitchen Taps

Pull out Rinser Kitchen Taps

Instant Boiling Water Taps

### **Insinkerator Waste Disposal Units**

**plumbworld**  
**Big brands, small prices.**