

Installation Instructions for Single Lever Kitchen Mixers

Preparation

First shut off your water heating system. Then, with your mains stop clock closed, open the lowest hot and cold taps in the house and allow water to run until the cold storage tank and pipes are empty. (The hot water storage cylinder always remains full).

Installation

First screw the threaded stud into the mixer body. Screw the flexible tails into the mixer body, and fully **hand tighten**. Ensure that Cold (blue) and Hot (red) are located correctly, cold on the right and hot on the left port. Place the sink mixer in position to see if any alteration to the existing supply pipework is necessary.

After making any necessary alterations to the pipework, pass the rubber washer over the flexible tails and threaded stud to form a seal on the sink top. Pass the flexible tails and fixing stud through the sink top from above, and place the mixer in position on the sink.

Slide the retaining plate up the flexible tails and secure, screwing the fixing nut.

Check that the mixer body is correctly positioned and fully tighten fixing nut.

It is recommended that 15mm x 15mm compression fitting be used to connect the mixer to the supply pipes. Hot water should be connected to the left when viewed from the front. The use of capillary fittings could invalidate your warranty.

Attention

Before installing the new mixer it is essential that you thoroughly flush through the supply pipes in order to remove any remaining swarf, solder or other impurities. Failure to carry out this simple procedure could cause problems or damage to the workings of the mixer. Having first checked all new connections, turn on the mains stop clock, close all taps except the new mixer and as the system starts to refill check for leaks.

Once you have satisfied yourself that there are no leaks, switch on the water heating.

Non return valves (NOT SUPPLIED) must be fitted on the hot side pipework.

Warning

These hints have been prepared for your guidance, you must exercise due care at all times. We do not accept responsibility for any problems that may occur through incorrect installation. While screwing the inlet flexible pipes to the body do not hold the top part of the body in order to avoid unscrewing it. If found to be necessary then hold onto the spout of the mixer.

NB. For safety, non return valves should be fitted to both hot and cold feed pipes.

How to Care for your kitchen sink mixer

To maintain the appearance of this fitting, ensure it is cleaned only using a clean, soft damp cloth. A solution of warm water and mild liquid detergent may be used where necessary, and then the fitting rinsed thoroughly. Abrasive cleaners or acidic cleansers **MUST NOT BE USED** under any circumstances. Avoid contact with all solvents.

Technical Data

Maximum water pressure: 75 PSI (5 bar)

Maximum hot-water temperature: 70 C

Recommended hot-water temperature: 65 C

Note: If these temperatures are exceeded, even for a short time, damage can result. Please read these instructions before you install and use the tap.

Check out our full range of Kitchen Products

Kitchen Sinks

Stainless Steel Kitchen Sinks

Granite Composite Kitchen Sinks

Glass Kitchen Sinks

Ceramic Kitchen Sinks

Franke Kitchen Sinks

Kitchen Taps

Contemporary Kitchen Taps

Traditional Kitchen Taps

Franke Kitchen Taps

Pull out Rinser Kitchen Taps

Instant Boiling Water Taps

Insinkerator Waste Disposal Units

plumbworld
Big brands, small prices.