




Instruction Manual



Please note that there is no No.2 panel !


Tools needed




churn drill




hammer




cross screwdriver




① x1 803*110*12mm




③ x4 681*105*12mm




④ x1 803*110*12mm




⑤ x1 803*110*12mm




⑥ x20 479*37*5mm




⑦ x1 803*168*12mm



⑧ x1 803*168*12mm



⑨ x1 860*190*12mm



⑩ x1 860*190*12mm



Ax3



Bx20




Cx22



Dx18



Ex40



Fx6



Gx6



Hx2




Ix8




Jx1



Using a screwdriver, screw in the #B screws securely. Please do not over tighten as it may cause wood to splinter. The small arrow on the #C Cam Locking Screw should be facing the #B screws extending from the panel. Use screwdriver to tighten securely, but avoid over tightening, screws may protrude through the panel.



1 2



Bx6


Cx6

Bx8


Cx8

Dx16

3 4



Ex40



Cx2


Dx2

Jx1




Keep the panels 9&10 on the same level when moving or the screws may protrude through the panels.

5 6



Bx6


Cx6



Hx2

Lx8

7 8



Ax3

Fx6

Gx6

